

Feature Operation

store	AutoD1		▶AutoD1
use		AutoD1	
display	Display	AutoD1	
place a call on hold			
return to a held call			
activate			
switch to handset			
handset to handsfree			
activate		Handsfree LED flashes	
Group Listening to handsfree		Handsfree LED is solid	
Group Listening to handset			
	Conf		▶Conf
Last Number Redial			
activate	RingAg		
when notified		▶RingAg	
cancel	▶RingAg		
activate	Forward		▶Forward
cancel	▶Forward		
reinstate	Forward	▶Forward	
view number	Display	▶Forward	
		PickUp	
answer			
return to first call			

Explanations

	Lift the handset, or press the DN key, or press the Handsfree key.
	Replace handset, or press to end the call.
	Dial a number.
	Press the line (DN) key.
▶AutoD1	The ▶ flashes when a feature is being programmed. The ▶ lights steadily when a feature is active.

Remarks

A Enter or edit the key label (maximum of 7 characters). To access special characters, press the Up Navigation Key. Use the Navigation Keys to locate the character you want to include. Press the Select Key to select the highlighted character. Press the Return Key to return to label entry without selecting a special character.

Programming your 3902 Digital Deskphone

Options List
Access the Options List
Select
Done Quit
Select / Select A Done Quit
Lower or Higher Done Quit
Select Lower or Higher Done Quit
Play Done Quit
On or Off Done Quit
Done Quit
On or Off Done Quit
On or Off Done Quit

For information on using your Avaya 3902 Digital Deskphone when connected to a Meridian SL-100 system, please consult the Avaya Digital Deskphones 3902, 3903, 3904 Quick Reference Guide.

For more information on the operation of your telephone, please consult the Avaya Digital Deskphones 3901, 3902, 3903, 3904 User Guide.

Introducing your Avaya 3902 Digital Deskphone



Avaya 3902 Digital Deskphone

Quick Reference Card

