EPDS | SENNHEISER



ADAPT 660

Over-ear Bluetooth[®] headset with ANC

User Guide

1

Contents

Package contents 3 Product overview 4 Overview of the headset 4 Overview of the longle 7 Overview of the longle 7 Getting started 8 Pairing the headset with Bluetonth devices 8 Using the audio cable 00 Using the USB cable 00 Installing the EPOS Connect app 11 Installing the EPOS Connect app 12 Turning the Bedset on and connecting it 12 Turning the headset of if 12 Turning the headset of if 12 Turning the neadset of if 12 Turning the headset of if 12 Turning the headset of if 13 Adjusting and waring the headset 13 Adjusting the headset of IANC) 14 Using Active Noise Cancellation (ANC) 14 Using Active Noise Cancellation (ANC) 14 Using the volce assistant / Alexa / voice diat 18 Making calls 19 Accepting / rejecting / ending acall 16 Accepting / rejecting / ending acall 16 Accepting	The ADAPT 660 headset	2
Overview of the leaded: 4 Overview of the leaded: 7 Overview of the leades: 7 Getting started 8 Pairing the headset with Bluetooth® devices 8 Using the sucie cable 10 Using the USB cable 10 Using the EPOS Connect app 11 Installing the EPOS Connect app 12 Turning the headset of the headset - Microsoft® Windows 11 Using the headset on and connecting it 12 Turning the headset of flag 12 Turning the headset of flag 13 Adjusting and wearing the headset 13 Muting the microphone 14 Uruning TabKinbough on / off 15 Making calls using the headset 16 Making actile 16 <	Package contents	3
Overview of the longle 7 Overview of the longle 7 Getting started 8 Pairing the headset with Bluetooth® devices 8 Using the endoc cable 10 Installing the FDOS Connect software 11 Installing the FDOS Connect software 11 Changing Audio settings for the headset - Microsoft® Windows 11 Using the headset 12 Turning Buetooth on / off 12 Turning Buetooth on / off 12 Turning the headset off 12 Adjusting the headset off 12 Adjusting the headset off 13 Adjusting the headset off 13 Adjusting the headset smicrophone volume for softphones 13 Making calls using the headset 16 Making a call 16 Redeling 17 Using the voloce assistant / Alexa / voice diall 18 Managing multiple calls. 19 Using the voloce assistant / Alexa / voice diall 16 Redeling 17 Using the eadset battery. 22 Verifying remaining battery power.		
Overview of the loads 77 Getting started 8 Pairing the headset with Bluetooth® devices 8 Using the sudio cable 10 Installing the EPOS Connect app 11 Installing the EPOS Connect software 11 Changing Audio settings for the headset - Microsoft® Windows 11 Using the Neadset on and connecting it. 12 Turning the headset off 12 Adjusting and weening the headset. 13 Adjusting and weening the headset. 13 Adjusting the headset in (ANC). 14 Turning Biat/hough on / off. 14 Using Active Noise Cancellation (ANC). 14 Turning Takit/hough on / off. 15 Making a call. 16 Accepting / rejecting / ending a call. 16 Making a call. 16 Making Microsoft® Teams and check hotifications. 20 Invoking Microsoft® Teams and check notifications. 20 Invoking Microsoft® Teams and check notifications. 20 Activating / deactivating the Smart Pause function. 23 Activating / deactivating the Smart Pause function. 23 <td< td=""><td></td><td></td></td<>		
Getting started 8 Pairing the headset with Bluetooth® devices 8 Using the uSB cable 10 Installing the FPOS Connect software. 11 Installing the FPOS Connect software. 11 Changing Audio settings for the headset - Microsoft® Windows 11 Using the headset 12 Turning the headset on and connecting it 12 Turning Buetooth on / off. 12 Turning the headset of. 13 Adjusting and wearing the headset. 13 Adjusting the headset of and connecting it for the headset. 13 Adjusting the headset. 13 Adjusting the headset. 13 Musing Active Noise Cancellation (ANC). 14 Turning Tak Nouse Cancellation (ANC). 14 Turning the voice assistant / Alwa / voice dial. 16 Making a cail. 16 Accepting / relecting / ending a cail. 17 Using Active Noise Cancellation (ANC). 17 Using the voice assistant / Alwa / voice dial. 18 Making a cail. 16 Accepting / relecting / ending a cail. 17 Using Active hage dust and charg	5	
Paining the headset with Bluetooth® devices		
Using the uulic cable 10 Using the USB cable. 10 Installing the EPOS Connect software. 11 Changing Audio settings for the headset - Microsoft* Windows 11 Using the headset 12 Turning the headset of and connecting it. 12 Turning the headset off. 12 Adjusting the volume 13 Adjusting the headset. 13 Adjusting the keadset. 13 Muting the microphone wolume for softphones. 13 Muting the microphone 14 Turning TakThrough on / off 15 Making a call 16 Accepting / rejecting / ending a call 16 Accepting / rejecting / ending a call 16 Macaging du using Microsoft* Teams / Cortana 20 Invoking Microsoft* Teams and check notifications 20 Invoking mutiple calls 19 Using headset and dongle with Microsoft* Teams / Cortana		
Using the USB cable 10 Installing the EPOS Connect app 11 Installing the EPOS Connect software 11 Changing Audio sattings for the headset - Microsoft® Windows 11 Using the headset on and connecting it 12 Turning the headset off 12 Turning the headset off 12 Adjusting the headset off 12 Adjusting the headset off 13 Adjusting the headset microphone volume for softphones 13 Muting the Noise Cancellation (ANC) 14 Turning like volce assistant / Alexa / voice dial 16 Making a call 16 Accepting / rejecting / ending a call 16 Redialing 17 Using Active Noise Constant / Alexa / voice dial 18 Managing multiple calls 19 Using the voice assistant / Alexa / voice dial 18 Managing multiple calls 20 Listening to audio using the headset 20 Invoking Microsoft® Teams / Cortana 20 Additional functions 20 Activating and using Microsoft® Teams / Cortana 22 Charging the sound effect. <td< td=""><td>0</td><td></td></td<>	0	
Installing the EPOS Connect app	-	
Installing the EPOS Connect software 11 Changing Audio settings for the headset - Microsoft® Windows 11 Using the headset 12 Turning the headset on and connecting it 12 Turning the headset of file 12 Adjusting and wearing the headset 13 Adjusting the headset of file 13 Adjusting the headset of file 14 Using Active Noise Cancellation (ANC) 14 Using Active Noise Cancellation (ANC) 14 Turning the volume 16 Accepting / rejecting / ending a call 16 Accepting / rejecting / ending a call 16 Accepting / rejecting / ending a call 16 Making and using Microsoft® Teams / Cortana 20 Using Active Sole Cortana 20 Using the headset tand chorgle with Microsoft® Teams / Cortana 20 Invoking Microsoft® Teams and check notifications 20 Activating and using the headset 21 Additional functions 22 Charging the headset battery. 22 Verifying remaining battery power 23 Activating / deactivating Call Enhancement 24 <t< td=""><td></td><td></td></t<>		
Using the headset 12 Turning the headset of and connecting it 12 Turning the headset off. 12 Adjusting and waring the headset. 13 Adjusting the wolume 13 Adjusting the headset's microphone volume for softphones 13 Muting the microphone 14 Using Active Noise Cancellation (ANC) 14 Turning TaikThrough on / off. 15 Making calls using the headset 16 Making a call. 16 Accepting / rejecting / ending a call 16 Redialing 17 Using Active Noise Consolitation (ANC) 18 Making a call. 16 Rectiging rejecting / relecting / ending a call 16 Rectailing 17 Using Atter Noise Consolit* Microsoft* Teams / Cortana 20 Invoking Microsoft* Teams and check notifications 20 Activating and using Microsoft* Teams / Cortana 20 Listening to audio using the headset 21 Additional functions 22 Charging the headset battery 22 Verifying remaining battery power 23	Installing the EPOS Connect software	
Turning the headset on and connecting it. 12 Turning Bluetooth on / off. 12 Turning the headset off. 12 Adjusting and waaring the headset. 13 Adjusting the headset's microphone volume for softphones. 13 Adjusting the headset's microphone. 14 Using Active Noise Cancellation (ANC). 14 Turning TaikThrough on / off. 15 Making calls using the headset 16 Making a call. 16 Accepting / rejecting / ending a call. 16 Redialing / rejecting / ending a call. 16 Making a call. 17 Using Active Noise Cancellation (ANC) 17 Using Microsoft* Cortana. 20 Invoking Microsoft* Teams and check notifications. 20 Activating and using Microsoft* Teams. 20 Activating on using the headset. 21	Changing Audio settings for the headset – $Microsoft^{\texttt{B}}$ Windows	11
Turning Bluetooth on / off 12 Turning the headset off 12 Adjusting and wearing the headset 13 Adjusting the volume 13 Muting the microphone 14 Using Active Noise Cancellation (ANC). 14 Turning TalkThrough on / off 15 Making calls using the headset 16 Maccepting / rejecting / ending a call 16 Accepting / rejecting / ending a call 16 Making a call 16 Making a call 16 Macaging multiple calls 19 Using headset and dongle with Microsoft® Teams / Cortana 20 Invoking Microsoft® Teams and check notifications 20 Activating and using Microsoft® Cortana 20 Listening to aucio using the headset 21 Additional functions 22 Charging the headset battery 22 Verifying remaining battery power 23 Activating / deactivating Call Enhancement 2	Using the headset	
Turning the headset off. 12 Adjusting and wearing the headset 13 Adjusting the volume 13 Adjusting the headset's microphone volume for softphones. 13 Muting the microphone 14 Using Active Noise Cancellation (ANC). 14 Turning TalkThrough on / off. 15 Making calls using the headset 16 Making a call. 16 Accepting / rejecting / ending a call. 16 Redialing 17 Using headset and dongle with Microsoft® Teams / Cortana. 20 Invoking Microsoft® Teams and check notifications. 20 Invoking Microsoft® Cortana. 20 Listening to audio using the headset. 21 Additional functions. 22 Charging the headset battery. 22 Charging the sound effect. 24 Activating / deactivating the Smart Pause function 23 Changing the Sideno. 24 Enabling / disabiling voice prompts, tones and changing language 25 Reponenting Additional functions 24 Charging the sound effect. 24 Activating / deactivating and using Microso		
Adjusting and wearing the headset 13 Adjusting the volume 13 Adjusting the headset's microphone volume for softphones 13 Muting the microphone 14 Using Active Noise Cancellation (ANC) 14 Turning Taik Through on / off 15 Making calls using the headset 16 Accepting / rejecting / ending a call 16 Accepting / rejecting / ending a call 17 Using the voice assistant / Alexa / voice dial 18 Manging multiple calls 19 Using headset and dongle with Microsoft [®] Teams / Cortana 20 Invoking Microsoft [®] Teams and check notifications 200 Activating and using Microsoft [®] Cortana 20 Additional functions 20 Charging the headset battery 22 Charging the sound effect 24 Activating / deactivating Call Enhancement 24 Adjusting the Sidetone 25 If you leave the Bluetooth range 25 Reconnecting Align voice prompts, tones and changing language 25 Reconnecting Pluetooth via the dongle 26 If you leave the Bluetooth range 26 <td></td> <td></td>		
Adjusting the volume 13 Adjusting the headsets microphone volume for softphones 13 Muting the microphone 14 Using Active Noise Cancellation (ANC) 14 Turning TalkThrough on / off 15 Making calls using the headset 16 Accepting / rejecting / ending a call 16 Accepting / rejecting / ending a call 16 Accepting / the volce assistant / Alexa / voice dial 18 Managing multiple calls 19 Using the volce assistant / Alexa / voice dial 18 Managing multiple calls 19 Using headset and dongle with Microsoft® Teams / Cortana 200 Invoking Microsoft® Teams and check notifications 200 Activating to audio using the headset 21 Additional functions 22 Charging the headset battery 22 Charging the badret power 23 Activating / deactivating the Smart Pause function 23 Charging the sound effect 24 Adjusting the Sidetone 24 Austivating / disabiling voice prompts, tones and changing language 25 Renabing / disabiling voice prompts, tones and changing lan	•	
Adjusting the headset's microphone 13 Muting the microphone 14 Using Active Noise Cancellation (ANC) 14 Turning TaikThrough on / off. 15 Making calls using the headset 16 Making call 16 Accepting / rejecting / ending a call. 16 Redialing 17 Using the voice assistant / Alexa / voice dial. 18 Managing multiple calls. 19 Using headset and dongle with Microsoft® Teams / Cortana. 200 Invoking Microsoft® Teams and check notifications. 200 Activating and using Microsoft® Cortana. 200 Listening to audio using the headset. 21 Additional functions 20 Charging the headset battery. 22 Charging the headset battery. 22 Verifying remaining battery power 23 Activating / deactivating the Smart Pause function. 23 Charging the sound effect 24 Adjusting the Sidetone. 24 Enabling / disabiling voice prompts, tones and changing language 25 Reconnecting / disconnecting Bluetooth range. 26 Storing an		
Muting the microphone 14 Using Active Noise Cancellation (ANC) 14 Turning TalkThrough on / off 15 Making calls using the headset 16 Making a call 16 Accepting / rejecting / ending a call 16 Rectailing 17 Using the voice assistant / Alexa / voice dial 18 Managing multiple calls 19 Using headset and dongle with Microsoft® Teams / Cortana 20 Invoking Microsoft® Teams and check notifications 20 Activating and using Microsoft® Cortana 20 Listening to audio using the headset 21 Additional functions 22 Charging the headset battery 22 Verifying remaining battery power 23 Activating / deactivating the Smart Pause function 23 Activating / deactivating the Smart Pause function 23 Activating / deactivating Butery power 24 Activating / deactivating Butery to wer 23 Activating / deactivating Butery to wer 24 Activating / deactivating Butery to wer 25 Reconnecting / disconnecting Bluetooth via the dongle 25		
Turning TalkThrough on / off	Muting the microphone	14
Making calls using the headset 16 Making a call 16 Accepting / rejecting / ending a call 16 Redialing 17 Using the voice assistant / Alexa / voice dial 18 Managing multiple calls 19 Using headset and dongle with Microsoft® Teams / Cortana 200 Invoking Microsoft® Teams and check notifications 200 Activating and using Microsoft® Cortana 200 Listening to audio using the headset 21 Additional functions 20 Charging the headset battery 22 Verifying remaining battery power 23 Activating / deactivating the Smart Pause function 23 Charging the sound effect 24 Activating / deactivating Call Enhancement 24 Activating / deactivating Buletooth via the dongle 25 Reconnecting / disconnecting Bluetooth via the dongle 25 If you leave the Bluetooth range 26 Maintaining the products 27 Replacing the erapats 27 Replacing the erapats 27 Replacing the erapats 27 Replacing the products <	o	
Making a call		
Accepting / rejecting / ending a call 16 Redialing 17 Using the voice assistant / Alexa / voice dial. 18 Managing multiple calls 19 Using headset and dongle with Microsoft® Teams / Cortana 20 Invoking Microsoft® Teams and check notifications. 20 Activating and using Microsoft® Cortana. 20 Listening to audio using the headset 21 Additional functions. 22 Charging the headset battery. 22 Verifying remaining battery power 23 Activating / deactivating the Smart Pause function. 23 Changing the sound effect. 24 Activating / deactivating Call Enhancement 24 Activating / disabling voice prompts, tones and changing language 25 Reconnecting / disconnecting Bluetooth via the dongle. 25 If you leave the Bluetooth range. 26 Storing and transporting the headset's rechargeable battery. 28 Mating the products. 27 Replacing the products. 27 Replacing the products. 27 Replacing / removing the headset's rechargeable battery. 28 If a problem oc		
Redialing 17 Using the voice assistant / Alexa / voice dial 18 Managing multiple calls 19 Using headset and dongle with Microsoft® Teams / Cortana 20 Invoking Microsoft® Teams and check notifications 20 Activating and using Microsoft® Cortana 20 Listening to audio using the headset 21 Additional functions 22 Charging the headset battery 22 Verifying remaining battery power 23 Activating / deactivating the Smart Pause function 23 Changing the sound effect 24 Activating / deactivating Call Enhancement 24 Adjusting the Sidetone 24 Enabling / disabiling voice prompts, tones and changing language 25 Reconnecting / disconnecting Bluetooth via the dongle 26 Storing and transporting the headset 27 Cleaning the products and updating the firmware 27 Cleaning the products 27 Replacing / the products 27 Replacing the ear pads 27 Updating the firmware of the products 28 Replacing / the products 28	· · · · · · · · · · · · · · · · · · ·	
Using the voice assistant / Alexa / voice dial. 18 Managing multiple calls. 19 Using headset and dongle with Microsoft® Teams / Cortana 20 Invoking Microsoft® Teams and check notifications. 20 Activating and using Microsoft® Cortana 20 Listening to audio using the headset 21 Additional functions. 22 Charging the headset battery. 22 Verifying remaining battery power. 23 Activating / deactivating the Smart Pause function. 23 Changing the sound effect. 24 Activating / deactivating Call Enhancement. 24 Adjusting the Sidetone. 24 Enabling / disconnecting Bluetooth via the dongle. 25 If you leave the Bluetooth range. 26 Storing and transporting the headset. 26 Maintaining the products and updating the firmware. 27 Cleaning the products. 27 Replacing the ear pads. 27 Replacing the earbeds's rechargeable battery. 28 Replacing the products. 27 Replacing the products. 27 Replacing the earbads. 27 <tr< td=""><td></td><td></td></tr<>		
Managing multiple calls. 19 Using headset and dongle with Microsoft® Teams / Cortana. 20 Invoking Microsoft® Teams and check notifications. 20 Activating and using Microsoft® Cortana. 20 Listening to audio using the headset. 21 Additional functions. 22 Charging the headset battery. 22 Verifying remaining battery power. 23 Activating / deactivating the Smart Pause function. 23 Changing the sound effect. 24 Activating / deactivating Call Enhancement. 24 Adjusting the Sidetone. 24 Enabling / disconnecting Bluetooth via the dongle. 25 If you leave the Bluetooth range. 26 Storing and transporting the headset. 27 Replacing the products and updating the firmware. 27 Cleaning the products. 27 Replacing the ear pads. 27 Updating the firmware of the products. 28 Replacing / removing the headset's rechargeable battery. 28 If a problem occurs 29 Clearing the pairing list of the headset (Reset) 30 Clearing the pairing list of the dongle	· · · · · · · · · · · · · · · · · · ·	
Invoking Microsoft® Teams and check notifications 20 Activating and using Microsoft® Cortana 20 Listening to audio using the headset 21 Additional functions 22 Charging the headset battery 22 Verifying remaining battery power 23 Activating / deactivating the Smart Pause function 23 Changing the sound effect 24 Activating / deactivating Call Enhancement 24 Adjusting the Sidetone 24 Enabling / disabling voice prompts, tones and changing language 25 Reconnecting / disconnecting Bluetooth via the dongle 25 If you leave the Bluetooth range 26 Storing and transporting the headset 26 Maintaining the products 27 Cleaning the products 27 Replacing the ear pads 27 Updating the firmware of the products 28 Replacing / removing the headset (Reset) 28 If a problem occurs 29 Clearing the pairing list of the headset (Reset) 30 Clearing the pairing list of the dongle (Reset) 30	0	
Activating and using Microsoft® Cortana. 20 Listening to audio using the headset. 21 Additional functions. 22 Charging the headset battery. 22 Verifying remaining battery power. 23 Activating / deactivating the Smart Pause function. 23 Changing the sound effect. 24 Activating / deactivating Call Enhancement. 24 Adjusting the Sidetone. 24 Enabling / disabling voice prompts, tones and changing language. 25 Reconnecting / disconnecting Bluetooth via the dongle 25 If you leave the Bluetooth range. 26 Storing and transporting the headset. 26 Maintaining the products and updating the firmware. 27 Cleaning the products 27 Replacing the ear pads. 27 Updating the firmware of the products 28 Replacing / removing the headset's rechargeable battery. 28 If a problem occurs 29 Clearing the pairing list of the headset (Reset). 30 Clearing the pairing list of the dongle (Reset). 30	Using headset and dongle with Microsoft® Teams / Cortana	
Listening to audio using the headset.21Additional functions.22Charging the headset battery.22Verifying remaining battery power.23Activating / deactivating the Smart Pause function.23Changing the sound effect.24Activating / deactivating Call Enhancement.24Adjusting the Sidetone.24Enabling / disabling voice prompts, tones and changing language.25Reconnecting / disconnecting Bluetooth via the dongle.25If you leave the Bluetooth range.26Storing and transporting the headset27Cleaning the products.27Replacing the ear pads.27Updating the firmware of the products.28Replacing the firmware of the products.28Replacing the pairing list of the headset (Reset).30Clearing the pairing list of the dongle (Reset).30		
Additional functions. 22 Charging the headset battery. 22 Verifying remaining battery power. 23 Activating / deactivating the Smart Pause function. 23 Changing the sound effect. 24 Activating / deactivating Call Enhancement. 24 Adjusting the Sidetone. 24 Enabling / disabling voice prompts, tones and changing language. 25 Reconnecting / disconnecting Bluetooth via the dongle. 25 If you leave the Bluetooth range. 26 Storing and transporting the headset. 26 Maintaining the products and updating the firmware. 27 Cleaning the products. 27 Replacing the ear pads. 27 Updating the firmware of the products. 28 Replacing / removing the headset's rechargeable battery. 28 If a problem occurs. 29 Clearing the pairing list of the headset (Reset). 30 Clearing the pairing list of the dongle (Reset). 30	Activating and using Microsoft® Cortana	
Additional functions22Charging the headset battery22Verifying remaining battery power23Activating / deactivating the Smart Pause function23Changing the sound effect24Activating / deactivating Call Enhancement24Adjusting the Sidetone24Enabling / disabling voice prompts, tones and changing language25Reconnecting / disconnecting Bluetooth via the dongle25If you leave the Bluetooth range26Storing and transporting the headset26Maintaining the products and updating the firmware27Cleaning the ear pads27Updating the firmware of the products28Replacing / removing the headset's rechargeable battery28If a problem occurs29Clearing the pairing list of the headset (Reset)30Clearing the pairing list of the dongle (Reset)30	Listening to audio using the headset	21
Verifying remaining battery power 23 Activating / deactivating the Smart Pause function 23 Changing the sound effect 24 Activating / deactivating Call Enhancement 24 Adjusting the Sidetone 24 Enabling / disabling voice prompts, tones and changing language 25 Reconnecting / disconnecting Bluetooth via the dongle 25 If you leave the Bluetooth range 26 Storing and transporting the headset 26 Maintaining the products and updating the firmware 27 Cleaning the products 27 Replacing the ear pads 27 Updating the firmware of the products 28 Replacing / removing the headset's rechargeable battery 28 Replacing the pairing list of the headset (Reset) 30 Clearing the pairing list of the dongle (Reset) 30 Clearing the pairing list of the dongle (Reset) 30	Additional functions	
Activating / deactivating the Smart Pause function.23Changing the sound effect24Activating / deactivating Call Enhancement24Adjusting the Sidetone.24Enabling / disabling voice prompts, tones and changing language25Reconnecting / disconnecting Bluetooth via the dongle25If you leave the Bluetooth range.26Storing and transporting the headset26Maintaining the products and updating the firmware.27Cleaning the products.27Replacing the ear pads.27Updating the firmware of the products.28Replacing / removing the headset's rechargeable battery.28Clearing the pairing list of the headset (Reset).30Clearing the pairing list of the dongle (Reset).30		
Changing the sound effect24Activating / deactivating Call Enhancement24Adjusting the Sidetone24Enabling / disabling voice prompts, tones and changing language25Reconnecting / disconnecting Bluetooth via the dongle25If you leave the Bluetooth range26Storing and transporting the headset26Maintaining the products and updating the firmware27Cleaning the products27Replacing the ear pads27Updating the firmware of the products28Replacing / removing the headset's rechargeable battery28If a problem occurs29Clearing the pairing list of the headset (Reset)30Clearing the pairing list of the dongle (Reset)30		
Activating / deactivating Call Enhancement 24 Adjusting the Sidetone 24 Enabling / disabling voice prompts, tones and changing language 25 Reconnecting / disconnecting Bluetooth via the dongle 25 If you leave the Bluetooth range 26 Storing and transporting the headset 26 Maintaining the products and updating the firmware 27 Cleaning the products 27 Replacing the ear pads 27 Updating the firmware of the products 28 Replacing / removing the headset's rechargeable battery 28 If a problem occurs 29 Clearing the pairing list of the headset (Reset) 30 Clearing the pairing list of the dongle (Reset) 30		
Adjusting the Sidetone		
Enabling / disabling voice prompts, tones and changing language 25 Reconnecting / disconnecting Bluetooth via the dongle 25 If you leave the Bluetooth range 26 Storing and transporting the headset 26 Maintaining the products and updating the firmware 27 Cleaning the products 27 Replacing the ear pads 27 Updating the firmware of the products 28 Replacing / removing the headset's rechargeable battery 28 If a problem occurs 29 Clearing the pairing list of the headset (Reset) 30 Clearing the pairing list of the dongle (Reset) 30		
If you leave the Bluetooth range		
Storing and transporting the headset 26 Maintaining the products and updating the firmware 27 Cleaning the products 27 Replacing the ear pads 27 Updating the firmware of the products 28 Replacing / removing the headset's rechargeable battery 28 If a problem occurs 29 Clearing the pairing list of the headset (Reset) 30 Clearing the pairing list of the dongle (Reset) 30		
Maintaining the products and updating the firmware 27 Cleaning the products 27 Replacing the ear pads 27 Updating the firmware of the products 28 Replacing / removing the headset's rechargeable battery 28 If a problem occurs 29 Clearing the pairing list of the headset (Reset) 30 Clearing the pairing list of the dongle (Reset) 30	•	
Cleaning the products. 27 Replacing the ear pads. 27 Updating the firmware of the products. 28 Replacing / removing the headset's rechargeable battery. 28 If a problem occurs 29 Clearing the pairing list of the headset (Reset). 30 Clearing the pairing list of the dongle (Reset). 30		
Replacing the ear pads 27 Updating the firmware of the products 28 Replacing / removing the headset's rechargeable battery 28 If a problem occurs 29 Clearing the pairing list of the headset (Reset) 30 Clearing the pairing list of the dongle (Reset) 30		
Updating the firmware of the products 28 Replacing / removing the headset's rechargeable battery 28 If a problem occurs 29 Clearing the pairing list of the headset (Reset) 30 Clearing the pairing list of the dongle (Reset) 30		
Replacing / removing the headset's rechargeable battery 28 If a problem occurs 29 Clearing the pairing list of the headset (Reset) 30 Clearing the pairing list of the dongle (Reset) 30		
If a problem occurs 29 Clearing the pairing list of the headset (Reset) 30 Clearing the pairing list of the dongle (Reset) 30		
Clearing the pairing list of the headset (Reset)		
Clearing the pairing list of the dongle (Reset)		
Specifications		
	Specifications	

The ADAPT 660 headset

Maximize focus and productivity anywhere with the ultimate headset powered by EPOS AI[™] for crystal clear calls, adaptive ANC and superior stereo sound. Enjoy a unique UC optimized solution with machine learning enhanced microphone performance.

Adaptive ANC helps you regain concentration by monitoring your working environment and adjusts noise reduction accordingly; even reducing wind noise when outdoors.

Get straight into collaborative work via a dedicated button that launches Microsoft Teams on your PC via the dongle included. Stay organized with Alexa voice assistant and connect simultaneously to mobile and PC.

Whether revitalizing your open office, working on-the-go, or enjoying a relaxed commute with superior stereo sound, ADAPT 600 boosts efficiency and improves wellbeing; an essential audio tool for today's mobile workforce.

Key benefits & features

Superb call clarity powered by EPOS AI™

Machine learning developed algorithms optimize voice pick up, for a natural listening experience from three advanced microphones

Regain concentration anytime, anywhere

Four adaptive ANC microphone system monitors your working environment and adjusts noise reduction in open offices, while reducing wind noise outdoors

Get organized with Alexa

Tap and hold to activate Alexa and stay on top of your day-to-day business. Never miss a meeting and plan your schedule both in and out of the office

Ensure clear calls with UC certified solution Certified for Microsoft Teams and optimized for UC

Experience superior sound to increase your focus

Renowned stereo sound and a personalized audio profile means you can enjoy high-quality music to help your focus on work



For safety instructions, consult the Safety Guide.

i.


A list of accessories can be found on the product page at www.eposaudio.com.

Trademarks

The Bluetooth[®] word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by DSEA A/S is under license. Qualcomm aptX is a product of Qualcomm Technologies International, Ltd. Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries, used with permission. aptX is a trademark of Qualcomm Technologies International, Ltd., registered in the United States and other countries, used with permission.


All other trademarks are the property of their respective owners.

Package contents



Product overview

Overview of the headset




Overview of the headset LED indications

00000	Headset connected
	Headset turned off
	Headset turns on
00000 3x	Bluetooth device found
	Incoming call
	Headset turns off
0000 0 3 x	Headset disconnected from mobile device/dongle
	Incoming call (rechargeable battery is weak)
00000	Headset in pairing mode:
	searching for mobile device/dongle
0000	Rechargeable battery is weak
0000	Battery power between 2 and 20%
00000	Battery power between 21 and 40%
00000	Battery power between 41 and 60%
00000	Battery power between 61 and 80%
0000	Battery power between 81 and 100%

*Once the headset is successfully connected, the LED goes off.

Overview of the headset controls



Touch pad	Тар	Function	Page
		Accepts a call	16
		2 calls: Answers incoming & ends active call	19
		Starts / pauses media playback	21
		Turns TalkThrough on/off (ANC turned on)	15
	-2x	Puts an active call on hold (pause) / unholds call	16
		2 calls: Answers incoming & puts active on hold	19
		2 calls: Toggles between two calls	19
	_(Rejects a call	17
	- 1s	Ends a call	16
		2 calls: Ends active & unholds paused call	19
		Activates voice assistant	10
		Activates Alexa	18
	4s	Requests remaining battery power	23
	Swipe	Function	Page
		Mutes the microphone	14
		Skips to the previous track	21
		Swipe and hold: Rewinds the track*	21
		Unmutes the microphone	14
		Swipe and hold: Redials the last number	17
\mathbf{h}		Skips to the next track	21
		Swipe and hold: Fast-forwards the track*	21
		Increases the volume	- 10
	➡	Decreases the volume	13

* These functions are not supported by all connected Bluetooth devices.


Bluetooth switch	Press	Function	Page
		Turns Bluetooth on	
	0	Turns Bluetooth off	12

Teams/Pairing button	Press	Function	Page
		Initiates a call	16
		Invokes Microsoft Teams	20
		Cancels pairing (Pairing mode)	8
	2x	Launches EPOS Connect app*	11
	() 1s	Activates Cortana	18
	(L)	Pairs the headset with a Bluetooth device	8
	4s	Clears pairing list (Pairing mode)	30

* These functions are not supported by all connected Bluetooth devices.

ANC switch	Press	Function	Page
		Turns ANC Maximum mode on	
		Turns ANC Adaptive mode on; adjustable via the EPOS Connect app	14
	0	Turns ANC off	

Overview of the dongle



Overview of the dongle LED indications

	3-83-83-83-	Dongle in pairing mode: searching for headset
	3x ≑ — €	Pairing successful
	3x ⇒ — ÷	Pairing failed
	;—; — ;—; —	Dongle tries to connect to a Bluetooth device
	; — ;	Dongle and Bluetooth device connected
	;—; — ;—; —	Incoming call
EPDS	;;	Outgoing/active callMedia playback
	÷÷	Connected to Teams
	;: - ;-: -	Teams notificationConnecting to Teams or Invoking Cortana
	३—६ — ३—६ —	Microphone of the connected Bluetooth device is muted

Overview of the dongle button

Link button	Press	Function	Page
	35	Pairs the dongle with the headset	8
		Reconnects the headset	25
	2x	Disconnects the headset	25

Overview of the icons

	Tap the button	i	Notes: Good to know
2x	Press the button twice		LED indications
35	Press and hold the button	3	Voice prompt is announced

Getting started

Pairing the headset with Bluetooth® devices




CAUTION Danger of malfunction!

The transmitted radio waves of mobile devices can impair the operation of sensitive and unprotected devices.

> Only use Bluetooth where it is permitted.

The headset complies with the Bluetooth 5.0 standard. Bluetooth devices need to support the "Hands-Free Profile" (HFP), the "Headset Profile" (HSP), "Audio Video Remote Control Profile" (AVRCP) or the "Advanced Audio Distribution Profile" (A2DP).



USB-C

•

USB-A

Connecting the headset via the dongle

To transmit data via Bluetooth, you first have to pair your headset to a wireless device. The delivered dongle is already paired with the headset.


The headset can save up to eight paired devices. If you pair the headset with a ninth device, the device with the oldest activity in the pairing list will be overwritten. If you want to re-establish a connection with this device, you have to pair it again.

The headset can be connected to two of the paired devices at the same time. You can only connect another device by disconnecting one of the already connected devices.

To connect the headset wirelessly with a computer, use the BTD 800 USB or BTD 800 USB-C dongle.

The dongle and the headset in the bundles are already paired.

- \triangleright Turn the headset on (see page 12).
- ▷ Plug the dongle into the USB port of your computer.



The dongle LED flashes blue while searching and switches to dimmed blue when connected successfully to the headset.

÷—÷ — ⇒—÷ — ▶ ÷—÷

If Microsoft Teams is invoked: The dongle connects to Teams and lights up purple instead of blue.


The dongle shows Teams notifications (see page 20).

- To manually pair the headset and the dongle, activate the pairing mode for both:
- Press and hold the headset's Teams/Pairing button and the dongle's button until the LEDs alternately flashes blue and red. Once the dongle and the headset are connected, the dongle lights up dimmed blue.


Pairing the headset via Bluetooth with a mobile device



> Twist the ear cups to turn on the headset.




Press and hold the Teams/Pairing button until the LEDs lights up white one after the other. The headset is in pairing mode.



Select "EPOS ADAPT 660" to establish a Bluetooth connection to the headset.


To cancel pairing: ▶ Press the Teams/Pairing button.



▷ Switch to position "I" to activate Bluetooth.




Enable Bluetooth on your mobile device and start the search for Bluetooth devices – see instruction manual of your mobile device.



One LED flashes 3 times white as soon as the headset finds a device to connect to. The LEDs turn off.

Using the audio cable

Use the audio cable for media playback when the battery is low or when Bluetooth transmission is restricted or not allowed. Bluetooth immediately turns off once the audio cable is connected to the headset.




- Insert the small jack plug into the audio socket of the headset.
 - Bluetooth is deactivated.
- Connect the 3.5 mm jack plug to the audio output of your mobile device.
- To disconnect the audio cable:
- Pull the plug out of the headset and your mobile device. The headset automatically tries to connect to available paired Bluetooth devices.

You can use the Active Noise Cancellation (ANC) as usual (see page 14).


Using the USB cable

Use the USB cable for calls via softphone or media playback via USB and charging.



- Connect the supplied USB cable to the USB socket of the headset and a USB socket of your computer. The battery is being charged – see page 22.
- ▷ Click the Audio icon on your PC and select EPOS ADAPT 660.

Installing the EPOS Connect app



Installing the EPOS Connect software




The free EPOS Connect app allows you to configure and update your headset and offers additional settings.

- Open the App Store or Google Play app on your mobile device.
- ▷ Search for "EPOS Connect".
- ▷ Download and install the app.

The free EPOS Connect software allows you to configure and update your headset and offers additional settings.

- Download the software from www.eposaudio.com/connect.
- Install the software.
 You need administrator rights on your computer if necessary, contact your IT department.
- To make calls via the computer:
- Install a softphone (VoIP Software) or ask your admin for support.

Changing Audio settings for the headset - Microsoft® Windows



Windows usually changes the Audio settings automatically if you connect a new headset.

If the headset is connected but you hear no sound:

- ▷ Right-click the Audio icon.
- ▷ Select under output ADAPT 660 as speaker.
- > Select under input ADAPT 660 as microphone.

Using the headset



Hearing damage due to high volumes!

- Listening at high volume levels for long periods can lead to permanent hearing defects.
- > Set the volume to a low level before putting on the headset.
- > Do not continuously expose yourself to high volumes.

Turning the headset on and connecting it




Twist the ear cups to turn on the headset. One LED flashes 3 times white. The headset automatically tries to connect to available paired Bluetooth devices.



One LED flashes 3 times white as soon as the headset finds a device to connect to. The LEDs turn off.

Turning Bluetooth on / off

> Turn Bluetooth on if you want to use the headset wireless.



Turning the headset off



- Twist the ear cups to turn off the headset. One LED flashes 3 times red. All volume settings are saved automatically when the headset is turned off.
- Charge the headset (see page 22). OR
- \triangleright Store the headset (see page 25).


Adjusting and wearing the headset


For good sound quality and best possible wearing comfort, adjust the headset.



Put the headset on so that the headband runs over the top of your head and the side with the R marking rests on your right ear.

Adjusting the volume





- > Adjust the headset so that
 - your ears are comfortably covered by the ear pads,
 - you feel even, gentle pressure around your ears,
 - a snug fit of the headband on the head is ensured.

You can adjust three independent volume settings for the headset:


- 1. Call volume: during an active call
- 2. Audio volume: during audio streaming
- Volume for ring tone, tones and voice prompts: in idle mode – no active call or audio streaming
- Swipe up or down to increase or decrease the volume. Depending on the length of the swipe, you can adjust the volume in smaller steps (short swipe) or in larger steps (long swipe).

You hear a double beep when the minimum or maximum is reached and louder or lower beeps for tones and voice prompts.

To protect your hearing when you switch the headset back on, very high volume levels are reset to a moderate level when switching off.


Alternatively you can adjust the volume on your connected device.

Adjusting the headset's microphone volume for softphones



- Initiate a call on your connected device to someone who will help you find the correct volume setting for your microphone.
- Change the microphone volume in your softphone application and/or in your PC audio application.

Muting the microphone



- Swipe
 - · backward to mute or
 - forward to unmute the microphone. You hear a tone.

Using Active Noise Cancellation (ANC)

This headset provides attenuation of ambient noise using Active Noise Cancellation (ANC) technology. Special microphones optimize speech and reduce background noise.


When "Adaptive ANC" is selected, active noise cancellation depends on the intensity of ambient noise. The active noise cancellation can be strong if the ambient noise is high, or weak if the ambient noise is low. You can control the extent of noise cancellation for the ANC Adaptive mode via the EPOS Connect app.




If you are in a noisy environment but would like to have your own quiet space, you can use the headset itself, disconnected from any device, and simply benefit from ANC. You can activate ANC if the battery is sufficiently charged and if the headset is turned on.

Good to know about ANC

- Continuous uniform noise, such as motor or fan noise, is suppressed
- Speech or high-frequency noise is reduced
- If a slight noise in very quiet environments occurs: Deactivate ANC.
- If unusual whistling or beeping noises occur: Take the headset off and put it on again and check the fit of the ear cups.



Adjusting the Adaptive ANC



The EPOS Connect app allows you to select different ANC modes that offer the optimal settings depending on the application/situation.

For example, low-frequency noise can be suppressed, wind noise can be minimized or a possible feeling of pressure on the ears can be avoided.

- ▷ Start the EPOS Connect app.
- ▷ Open Noise Cancellation.
- > Change the intensity of the Noise Cancellation.

Turning TalkThrough on / off


TalkThrough allows you to communicate with your colleagues without having to remove the headset, even when ANC is turned on. Media playback will be paused or muted.



Making calls using the headset

The following functions depend on the connected device.

Making a call




 \triangleright Initiate the call on your connected device.

OR


- Press the Teams/Pairing button to initiate a call via your softphone.
- If your call is not automatically transferred to the headset:
- Search this function in the instruction manual of your connected device.

Accepting / rejecting / ending a call

When you receive a call, you hear a ring tone and the LED flashes blue.



Accept / hold a call



If Smart Pause is activated (see page 23):


Lift the headset from the desk and put it on. The sensor registers motion and the incoming call is accepted.

▷ Lay down the headset.


The call is put on hold.

 $\triangleright\,$ Put the headset on again to resume the call.

Reject / end a call




Redialing



Using the voice assistant / Alexa / voice dial


The last connected Bluetooth device will be used for voice assistant or voice dial. For Microsoft Cortana: see page 20.

Before you can use Amazon Alexa as a voice assistant, you have to add the headset to the Amazon Alexa app – see below.



Ĩ

Connecting the headset to Amazon Alexa



- ▷ Start the EPOS Connect app on your mobile device.
- Open the settings and activate Amazon Alexa for your ADAPT 660 headset.
- ▷ Start the Amazon Alexa app and select Add Device.
- Select ADAPT 660 from the list of found devices to connect the headset to Alexa.

There are on-screen notifications to guide you through the settings.

Managing multiple calls




Accept / reject second call


You can use the Headset with up to two connected Bluetooth devices.

Two calls can be managed simultaneously.


If you receive a call during an active call, a knock on tone will be played.



Toggle between calls / end active call




Using headset and dongle with Microsoft® Teams / Cortana




- To use Microsoft Teams and Cortana with the headset:
- Plug the dongle into the USB port of your computer see page 8.
 - If Microsoft Teams is already running, the blue LED changes to purple automatically.

Invoking Microsoft® Teams and check notifications



Activating and using Microsoft® Cortana



- ▷ Start Microsoft Teams on your computer.
- The dongle connects to Microsoft Teams and the LED blue LED changes to purple.



The LED pulses purple to indicate:

- Meeting Join Notification
- Voice Mail Notification
- Missed Call Notification

To check these Notifications on your screen:

▷ Press the Hook button.

You can activate and use Cortana – Microsoft's Personal Digital Assistant using Voice command technology – with the headset.

Press the Teams/Pairing button. The Dongle LED flashes purple while activating Cortana.


÷—÷ — ÷—÷ —

The LED lights up purple and Cortana is ready to use. $\frac{1}{2}$

Listening to audio using the headset

You can listen to audio via a connected device. The following functions depend on the connected device.

Play the media on your connected Bluetooth device. The LED on the dongle lights up blue.



If you receive and accept a call, media playback is paused and restarts after the call – if supported by the connected device.

If Smart Pause is activated (see page 23):



i


> Lay down the headset to pause media playback.



> Put on the headset to resume media playback.

Additional functions

Charging the headset battery



Connect the supplied USB cable to the USB socket of the headset and a USB socket of your computer. The battery is being charged. The LEDs light up depending on the battery status of the headset and turn off when the battery is fully charged.

LED	Battery status	LED	Battery status
0000	between 81 and 100%	00000	between 21 and 40%
0000	between 61 and 80%	0000	between 2 and 20%
00000	between 41 and 60%	0000	weak: <2%

To end charging:

▷ Disconnect the USB cable from the headset.

• When the battery is flat, the headset turns off automatically.

Switch the headset off for faster charging.

0000

Verifying remaining battery power



The remaining battery power is shown in the EPOS Connect app.

Some mobile devices indicate the battery status of the headset.


You can retrieve information on the remaining battery power at any time – except while you are in a call: > Tap and hold the finger on the touch pad until a voice prompt is announced.

_	LED	Remaining battery power
	0000	more than 80%
	0000	more than 60%
	00000	more than 40%
	00000	more than 20%
	0000	more than 2%

When the battery power drops below 2%, the LED flashes red and "Recharge headset" is announced several times.

Activating / deactivating the Smart Pause function

The headset is equipped with a motion sensor that registers when the headset is put in or out of rest position. By factory default, Smart Pause is inactive.




You can use the following functions:

- Media playback pauses when you remove the headset and continues when you put it on again.
- A call is accepted when you put on the headset
- A call is put on hold when you remove the headset during a call and resumed when you put it on again.
- ▷ Start the EPOS Connect app.
- ▷ Go to Settings.
- > Activate or deactivate Smart Pause.

Changing the sound effect

You can use these settings to enhance the quality of your audio according to its genre or category.



The sound effects are automatically activated when the headset and the mobile device are connected via Bluetooth or the USB cable.




To change the sound effect:

- ▷ Start the EPOS Connect app.
- > Open Acoustic modes.
- ▷ Swipe to your mode see table below.
- Go back to the home screen to save the setting in the app and for the headset.

Mode	Meaning
Neutral	neutral setting
Club	for more room impression
Movie	for more exciting entertainment
Speech	for higher intelligibility e.g. podcasts or audiobooks
Director	 Tap on Adjustment, to customize the settings: Boost: raises certain frequency ranges Spatial: simulates virtual external speakers Reverb: simulates a virtual room DLC: dynamic level control

Activating / deactivating Call Enhancement



This function reproduces the voice of the person you are talking to so naturally that you get the impression that the person is in the same room and not at the other end of the line.



- Start the EPOS Connect app.
- ▷ Go to Settings.
- > Activate or deactivate Call Enhancement.

Adjusting the Sidetone





Sidetone is the audible feedback of your own voice during a phone call.



- ▷ Start the EPOS Connect app.
- ▷ Go to Settings.
- \triangleright Move the slider to the desired strength for the Sidetone.



You can also change these settings via EPOS Connect.


Enabling / disabling voice prompts, tones and changing language

You can change voice prompts, tones and language via the EPOS Connect app.



You can also change these settings via EPOS Connect.

Enabling / disabling voice prompts and tones



Changing the language of the voice prompts




- Start the EPOS Connect app.
- ▷ Go to Settings.
- ▷ Tap on Tone & Voice prompts.
- ▷ Tap on:
 - Off
 - deactivates tones and voice prompts (few exceptions e. g. rechargeable battery is empty)
 - Tone only deactivates voice prompts
 Tone & Voice prompts
 - activates tones and voice prompts

By factory default, voice prompts are activated in English.

- ▷ Start the EPOS Connect app.
- ▷ Go to Settings.
- ▷ Tap on Tone & Voice prompts.
- ▷ Tap on Language of voice prompts and choose the corresponding language from the list.

Reconnecting / disconnecting Bluetooth via the dongle



Reconnecting Bluetooth


Tap the dongle's button. The dongle flashes blue and lights up dimmed blue.

Disconnecting Bluetooth

Double tap the dongle's button. Bluetooth will be disconnected. The LED flashes 3 times red.


If you leave the Bluetooth range

The range between headset and Bluetooth device is device dependent. The transmission range largely depends on environmental conditions such as wall thickness, wall composition etc. With a free line of sight, the transmission range of most Bluetooth devices is up to 25 meters.



If the audio quality deteriorates e.g. during a call or the link breaks down completely:

▷ Re-enter the radio range of the Bluetooth device.




If you re-enter the Bluetooth transmission range within 5 minutes, the connection is re-established.

After more than 5 minutes re-establish the connection manually:

> Turn the headset off and on again.



Storing and transporting the headset



To avoid nicks or scratches on the headset:


- > Fold the ear cups inwards towards the headband.
- > Store the headset in the case when not in use or when carrying it around. Keep it in a clean and dry environment.

If you do not use the headset for extended periods of time:

▷ Charge the built-in rechargeable battery every 3 months for about 1 hour.

Maintaining the products and updating the firmware

Cleaning the products



CAUTION


Liquids can damage the electronics of the product!

Liquids entering the housing of the device can cause a short circuit and damage the electronics.


- ▷ Keep all liquids far away from the product.
- > Do not use any cleansing agents or solvents.
- > Only use a dry cloth to clean the product.

Replacing the ear pads

For hygienic reasons, you should replace the ear pads from time to time. Spare ear pads are available from your EPOS partner.



Grab under the ring of the earpad from the outside and pull it off the ear cup hooks.




> Put the new earpad on the upper and lower hooks and press on all corners of the ear cup to securely lock it.

Updating the firmware of the products

To update the installed firmware:

▷ Install the free of charge EPOS Connect software (see page 11).

Updating the firmware of the headset




Connect the USB cable to your headset and your computer. The LEDE light up





Updating the firmware of the dongle



Plug the dongle into the USB port of your computer. The LED lights up.

▷ Start EPOS Connect.

If there is a new firmware available the software will guide you through the update process.

Replacing / removing the headset's rechargeable battery

The rechargeable battery must only be replaced or removed by an authorized EPOS service center.

Contact your EPOS service center if the rechargeable battery needs to be replaced. To find the EPOS service partner in your country, visit www.eposaudio.com.


Outside the warranty period, the rechargeable batteries may be replaced or re-moved by any qualified service center.

If a problem occurs ...


Problem	Possible cause	Solution	Page
Headset cannot be turned on	Rechargeable battery empty	Recharge the headset battery.	22
Active Noise Cancellation (ANC) cannot be turned on	Rechargeable battery empty	Recharge the headset battery.	22
	Headset turned off	▷ Turn the headset on.	12
No audio signal or drop outs	Headset not paired with a Bluetooth device	Pair the headset.	8
	Volume adjusted too low	Increase the volume.	13
	Headset turned off	▷ Turn the headset on.	12
	Computer: Headset not selected as audio device	Change the Audio settings of your computer.	11
Headset cannot be connected via Bluetooth	Headset not paired	 Pair the headset with a Bluetooth device (max. 20 cm distance while pairing between devices). 	8
		Check if your Bluetooth device supports the HF or HS profile.	-
	Bluetooth at headset turned off	▷ Turn Bluetooth on.	12
	Bluetooth at mobile device turned off	▷ Turn Bluetooth on.	-
	Dongle not plugged in	Plug the dongle into the USB port of your Computer.	8
Microsoft Teams does not	Dongle or Microsoft Teams	Unplug and plug the dongle again.	-
work: LED blue instead of purple	disturbed	▷ Re-start Teams on your device.	-
Beeps instead of voice prompts	Voice prompts disabled	▷ Enable the voice prompts.	25
Headset does not respond to Smart Pause	Smart Pause is deactivated by factory default	Activate Smart Pause via the EPOS Connect app.	23
gestures	Smart Pause may not be compatible with your media player	Try another media player or streaming app.	-
Headset or dongle does not react to any button	Software or hardware problems	▷ Turn the headset off and on again.	12
		Unplug and plug in the dongle again.	8
press		Clear the pairing list of the headset.	30
		> Clear the pairing list of the dongle.	30

If a problem occurs that is not listed in the above table or if the problem cannot be solved with the proposed solutions, please contact your local EPOS partner for assistance. To find the EPOS partner in your country, search at www.eposaudio.com.


Clearing the pairing list of the headset (Reset)




 Press and hold the Teams/Pairing button until the LEDs lights up white one after the other. The headset is in pairing mode.



Press and hold the Teams/Pairing button until the LED flashes red 3 times.
 The pairing list is cleared. The headset searches for Bluetooth devices to pair with – see page 8.



- ▷ Plug the dongle into the USB port of your computer.
- Press and hold the button until the LED flashes blue and red.



Double press the dongle's button. The LED flashes purple 3 times. The pairing list is cleared. The dongle searches for Bluetooth devices to pair with – see page 8.

Clearing the pairing list of the dongle (Reset)

Specifications

Headset - General

Wearing style Dimensions (W x H x D) Weight Transducer principle Connectivity

Supported Bluetooth profiles

Supported codecs Rechargeable battery (built-in) Charging time Standby time Battery time Range

Headset - Audio

Speaker frequency response17 HzSound pressure level (SPL)Max.Total harmonic distortion (THD)< 0.50</td>Noise cancellationHybridMicrophone typeDigitalMicrophone frequency response150 HImpedanceactiveContact pressure3 NTotal noise attenuationUp to

Dongle BTD 800 USB

Dimensions (W x H x D) Weight Connector Connectivity Output power

Dongle BTD 800 USB-C

Dimensions (W x H x D)
Weight
Connector
Connectivity
Output power

Over-ear, double-sided headband

63 x 136 x 174 mm / 2.48 x 5.35 x 6.85 in

227 g / 8 oz

Dynamic, closed

• Bluetooth 5.0

audio cable (2.5 mm and 3.5 mm jack plugs)

USB cable with micro-USB connector

Hands-Free Profile (HFP), Headset Profile (HSP), Audio Video Remote Control Profile (AVRCP), Advanced Audio Distribution Profile (A2DP)

AptX™, AptX™ low latency, AAC, SBC

Lithium Polymer / 3.7 V DC / 730 mAh

3 hours

Up to 15 days

Up to 30 hours (ANC on, Bluetooth off)

Up to 25 m / 82 feet (device dependent)

17 Hz to 23,000 Hz	
Max. 118 dB limited by EPOS ActiveGard®	
< 0.5% (1 kHz, 100 dB)	
Hybrid adaptive ANC technology with 4 microphones	
Digital MEMs beamforming microphone (3 microphones)	
150 Hz to 6,800 Hz	
active: 490 Ω / passive: 46 Ω	
3 N	
Up to 30 dB	

22 x 16 x 6 mm / 0.87 x 0.63 x 0.24 in
2 g / 0.07 oz / 0.004 lbs
USB-A plug
Bluetooth 4.2
max. 8 dBm (EIRP)

27.5 x 23.5 x 7.5 mm / 1.05 x 0.93 x 0.30 in
2.8 g / 1.0 oz / 0.006 lbs
USB-C plug
Bluetooth 4.2
max. 11 dBm (EIRP)

EPDS | SENNHEISER



DSEA A/S

Kongebakken 9, DK-2765 Smørum, Denmark www.eposaudio.com