

Doro MemoryPlus 309dp

Photo button dial pad

MemoryPlus 309dp makes dialling frequently used numbers much easier. This accessory can be connected with an existing phone to conveniently provide one-touch dialling using large easy to recognize photo buttons.

- ✓ One-touch photo buttons
- Use with existing phone
- Extremely easy to understand and use



Doro MemoryPlus 309dp

Main features Photokeys 6 Ergonomics Easy clean surfaces Low profile front for easy operation Desktop placement Powering handset unit Battery included (type) Li Technology PSTN

Doro shall not be held responsible for any errors or omissions contained herein. Specifications are subject to change without notice.

